



| TAGLIERI IN POLIETILENE - POLYETHYLENE CHOPPING BOARDS - PLANCHES À HACHER EN POLYTHÈNE - HACKBRETTE AUS POLYÄTHYLEN  |                 |  |
|---|-----------------|--|
|  <p>PER SCELTA COLORE<br/>AGGIUNGERE AL CODICE:<br/>Y = GIALLO<br/>B = BLU<br/>M = MARRONE<br/>R = ROSSO<br/>G = VERDE</p> | <b>TP 40302</b> | 40x30x2 h bianco/white   |
|   | <b>TP 50302</b> | 50x30x2 h bianco/white   |
|   | <b>TP 50402</b> | 50x40x2 h bianco/white   |
|   | <b>TP 60402</b> | 60x40x2 h bianco/white   |
|   | <b>TP 70402</b> | 70x40x2 h bianco/white   |
|   | <b>TP 80402</b> | 80x40x2 h bianco/white   |
|   | <b>TP 50302</b> | 50x30x2 h colorato: giallo, blu, marrone, rosso verde<br>coloured: yellow, blue, brown, red, green |
|   | <b>TP 60402</b> | 60x40x2 h colorato: giallo, blu, marrone, rosso verde<br>coloured: yellow, blue, brown, red, green |

| RASCHIETTO - BRUSH - BROSSE - REINIGUNGSBÜRSTE                                    |              |   |
|---|--------------|---|
|  | <b>RASK</b>  | Raschietto per pulizia ceppi e taglieri<br>Brush for chopping blocks and chopping boards cleaning |
|   | <b>RICRA</b> | Ricambio lama per raschietto - Blade spare part for the brush                                     |
|   |              |   |